

## Engage. Explore. Empower.

Connecting Visionaries in Radiation Safety, Science and Industry



Annual Users' Conference

July 29 - August 2 | Omni Dallas Hotel, Dallas, TX



# MC24 – Breakout Session Dosimetry

### **BLEUSE Olivier**

Dosimetry & Telemetry - Product Line Manager

Mirion Connect | Annual Users' Conference 2024

Dallas, Texas



## Agenda

- DMC 3000 & The Modular Approach
- G2 Protocol & Upgrade to G3
- DMC 3000 & Modules
- Measurement Modules / Telemetry Modules
- DMC 3000 Bluetooth & Connected Ecosystem
- C&C Dosimetry Integration
- DosiServ Convergence Project
- Updates & News on The Dosimetry Line



# Mirion Technologie: Dosimetry Solution Provider since 1980

- 1 Million of DMC
   civils & military in service
- Dosimeter Design for Everyone & all Purposes
- Used in more of 70% of Reactors W/W
- Full & Complete Ecosystem
- Robust, Recognized & Qualified with Market Standard (IEC & Other)















## **Electronic Dosimetry Development Timeline**

SOR/RF **DMC-3000 DMC-90 DMC-100 DMC-2000GN** DM-20 **DM-60 DMC-2000S** · Enhanced detector for wider energy range Vibration Commercial • Enhanced EMI immunity version derived Larger display from NATO SOR Brighter LED • Modular Enhanced EMI Gamma & immunity Neutron version 1980 1988 2010 2013 to present..... SOR/T DMC-2000X **DMC-2000XB** SOR/R Telemetry Beta Neutron Module Module Module · X-Ray and Beta versions · NATO ambient & tactical · WRM2 Remote Smart modules · Surface mounted board monitoring system • Interchangeable components



Neutron Tx

Module

Location Tx


Module

BLE

Module

# Mirion Electronic Dosimetry

An Integrated Solution





Engage. Explore. Empower.

## Electronic Dosimetry Product Line



## Highlight: DMC 3000 More than 350 k units sold

- Ruggedness and Durability
- Loud audible, ultrabright visual and tactile vibration alarms
- Best in class metrological performance
- Best in class battery life
   (12 calendar months with standard COTS AAA battery)
- Highly visible backlit display
- IP67 waterproof & easily decontaminated
- Excellent EMI immunity
- Modular Design
- Complete Ecosystem
- TTRs available & done by third party lab

Engage. Explore. Empower.

Annual Users' Conference

## **DMC 3000**

- One DMC 3000 dosimeter for the several uses
- Extend measures & connectivity
- Easy Plug and Play
- Be prepared for the future ...






© 2024 Mirion Technologies. All rights reserved.

### DMC 3000: G2

## **G2 Protocol:**

- Minimize the impact of change for existing installations
- Introduce the new Dosimeter without a new qualification of the existing installation (software and hardware qualifications)

- DMC 3000 with G2 Protocol:
- Most standard functions identical to DMC 2000
- Backwards Compatible with existing reader
- Generally compatible with older software
- Fully compatible with:
  - Sentinel
  - His-20
  - DosiServ






## DMC 3000: Why to upgrade to G3

#### **G3 Protocol:**

- Native DMC3000 Protocol
- More features:
  - Compatible with all modules
  - Enhanced dosimeter self check
  - Enhanced secured communication protocol CRC 32bits
  - Additional features Histogram (dose/dose rate; raw pulse; auto adaptive; etc..)
  - More display options (customizable)
  - More options (calibration factor, configurations, data resolution, data stored, speaker self test, speaker volume option, etc..)





## DMC 3000: Why to upgrade to G3

				Dose	Rate
95	13:18:55	Measure		22.2	14.9
94	13:19:50	Measure			
93	13:19:55	Measure		22.6	41.9
91	13:20:11	Measures after rate alarm		23	67.5
90	13:20:12	Measures after rate alarm		23	67.5
89	13:20:13	Measures after rate alarm		23	67.5
88	13:20:14	Measures after rate alarm		23	67.5
87	13:20:15	Measures after rate alarm		23.1	108.6
92	13:20:16	Event	Primary rate alarm		
86	13:20:16	Measures after rate alarm		23.1	108.6
80	13:20:16	Measure			
85	13:20:17	Measures after rate alarm		23.1	108.6
84	13:20:18	Measures after rate alarm		23.1	108.6
83	13:20:19	Measures after rate alarm		23.1	108.6
82	13:20:20	Measures after rate alarm		23.1	108.6
81	13:20:24	Event	Primary rate alarm end		
79	13:20:55	Measure		23.3	21.8
78	13:21:40	Measure			
77	13:21:55	Measure		23.6	24.7



## DMC 3000: How to upgrade to G3

















**Evolution to G3 Protocol (FW: V7.8.6)** 





- Mirion On-Site Update
- Mirion Factory Return

## DMC 3000: How to add/remove a module



## **Connector**









Engage. Explore. Empower.

## DMC 3000: How to add/remove a module











Engage. Explore. Empower.

## DMC 3000: How to add/remove a module







Faulty/removed Module


 Wrong Module connected

## DMC 3000:

#### How to remove a module and clear the mod Def?



 Remove /Replace the battery to clear the MOD\_DEF  Or detach the module by DMCUser



Go to Pause


Detach Module



Go to Measure

Options

## DMC 3000 Neutron module





Engage. Explore. Empower.

© 2024 Mirion Technologies . All rights reserved.

Annual Users' Conference

## DMC 3000 Telemetry module

- WRM compatibility
  - WRM2 / WRM3
    - Provides real-time readouts and statuses of transmitter
    - Enables a supervisor outside a radiation work area to be instantly alerted to alarm conditions happening inside.
    - Compact and rugged equipment for indoor or outdoor applications.
    - Roughly 6000ft Line-of-Sight range, extendable with the use of MESH Repeaters
- AAA Battery
- Autonomy ~ 30 hours + 8 hours guaranty
- IP 67, Ruggedness and Durability, Excellent EMC Immunity





## DMC 3000 Telemetry module

Orion RTLS utilizes the established technology of the DMC 3000

dosimeter, fitte

 The LTx modul information a visualization o

- LTx module feat
  - Ultra Wide
  - WRM2/3 information
  - Communic
     for radiol
  - Powered in (module fa

**Breakout Session Dedicated** 

Today – Orion RTLS 4:00 – 5:00

Demo Room

Thursday - Telemetry
11:30 - 12:30





# DMC 3000 Bluetooth & Connected Ecosystem





#### An additional DMC 3000 Bluetooth® module what for?





# "Enhance your safety with connectivity"

**New Bluetooth® Module** 



## What is connectivity? Whats is the value proposition for RP?


#### **Connectivity:**

- ability to connect systems or application program
- do not require many changes to the application or the systems they run on
- helping to reduce worker exposures
- telemetry is reducing around 20% dose exposure

**Connecting workers** offers a more sophisticated system to ensure safety

- Autonomous monitoring
- Supervised monitoring
- Get the data you need
- Receive instant update
- Increase reaction
- Reduce the risk





Engage. Explore. Empower.

© 2024 Mirion Technologies. All rights reserved

# Value Proposition for NPP / Labs Industry Market

#### Enhance dosimeter alarm for challenging environment

#### Increase the alert

- Visualize the alert
- Transmit the alert

#### Have ease of use

- To have correct form factor
- To be used on daily tasks & integrated on current procedures

Ensure the dosimeter is being worn

#### **DMC 3000 BLE & Connected Ecosystem**

## "Enhance your safety with connectivity"



New Bluetooth module

Mirion Watch additional remote alarm

ConnectStudio
Connectivity
Management



Engage. Explore. Empower.

## **DMC 3000 BLE: Form Factor**



#### **Maintains DMC 3000 current form factor**

- Designed for an easy pairing
- Compatible with all DMC 3000\*
- A simple extended battery cover

**Battery Cover** 





### DMC 3000 Bluetooth® Module, How Does it Look Like?


#### **Perform a quick & easy pairing** operations with dosimeter and connected devices

#### What's pairing?

Association between the dosimeter and one peripheral to initiate communication

#### What's NFC?

NFC: Near Field Contact Very shortrange communication



Each Mirion device is able to **exchange data** through NFC, which permits the exchange of the necessary information to perform devices association



## Mirion Watch: Reinforce Dosimetry Alarm for Challenging







## **Advantages:**

- Easy pairing & Easy to use
- Vibrating device in case of alarm
- Display information on alarm type



## ConnectStudio & Connected Ecosystem



Feature 1:
Easy pairing between
DMC 3000 and peripherals



Feature 2:
Wireless Supervision
(short range ~25 meters)

## Feature 3: Bridge to Mirion WRM™ system (long range Telemetry ~1000 meters)

Engage. Explore. Empower.


© 2024 Mirion Technologies . All rights reserved.

Annual Users' Conference

## Mirion Watch: Reinforce Dosimetry Alarm for Challenging

#### **Controlled area**











**VIBRATION** 

Designed to enhance safety for any tasks (Time alarm / Dose Alarm / Dose Rate Alarm) Easy decontamination





## Mirion Watch Association at RCA entry




LDM 3200 NFC updated for an easy use on daily task

- Quick & Easy Pairing
- Quick & Easy Unpairing


## MirionWatch association at RCA entry: Charging Rack solution

- Available solution for charging Mirion Watch (10 units)
- Visible at a glance of Mirion Watch battery status when on rack
- 8 hours of use guaranteed by color displayed ( or )





Local supervision in RCA by team leader for special operation







## Local & Long Range Wireless Supervision (Bluetooth and WRM Network)

#### **Local Telemetry by Bluetooth®**

## **Controlled area TelemetryStudio** TeleView 3000 **Local Supervision** Orion

- ConnectStudio as a bridge to WRM Network
- Control room has access to local supervision data
- Leverage your existing Telemetry System




#### **Control Room Supervision**

**Long Range Telemetry by WRM<sup>TM</sup> Network** 

## **Nuclear Glove Box & Wireless supervision**

ConnectStudio

# Single & Dual monitoring solution



ConnectStudio



## With Mirion Watch, Never Forget your Dosimeter in RCA





## **DMC 3000 Bluetooth & Connected Ecosystem**

#### **Long Range Telemetry**



900 MHz (US market) 2,4 GHz (EU market) WIFI / WIRED communication

#### **Short Range Telemetry**




Custom development

> **WRMNet** Licence







#### **Dosimeter Alarm** Reinforcement





- Mirion Product
- Mirion Upgrade
- Mirion based provided, ready for customization
- Wired link
- Local Network Engage. Explore. Empower.

**Mobility** 

WRMNet Licence



© 2024 Mirion Technologies. All rights reserved.

### DMC 3000 BLE & Ecosystem

DMC & MirionWatch Automatic Pairing



ConnectStudio



AWM<sup>TM</sup>
(Adaptive Wireless Monitor)

Feature 1:
Easy pairing between
DMC 3000 and peripherals

Annual Users' Conference



Feature 2:
Wireless Supervision

(DMC short range ~25 meters)

DMC & RDS 32+probes Automatic Pairing Feature 3:
Bridge to Mirion WRM™ system
(long range Telemetry ~1000 meters)
Bridge to local network
(Wifi, Lan, other technology)

Engage. Explore. Empower.

© 2024 Mirion Technologies. All rights reserved.

## DMC 3000 BLE & Ecosystem











#### **Advantages:**

- Easy pairing & Easy to use
- Vibrating device in case of alarm
- Display information on alarm type
- Alarm / Information easily reported

#### **New Information Features**

- Autopairing to last DMC
  - Time / Time in run
  - Dose / Dose Rate
- Dose Alarm / Dose Rate Alarm
  - Wearer Name / RWP
    - A lot more...







Engage. Explore. Empower.

© 2024 Mirion Technologies. All rights reserved

## DosiServ Convergence Project





### DosiServ: Dose Management SW



#### DosiServ is enhancing to be Best in Class Dose Managt SW

- HIS 20 is maintained, developed, supported & still proposed


#### **Creation of DosiServ User Group (2025)**

- Publication bi semestrial on Use Cases / Advantages
- Other actions to follow

Communication to follow (Sept-Oct 2024)



### **DosiServ: Dose Management SW**



- Improved UX/UI
- Compliance with new SISERI export
- BLE module management

ement improvement

rement

nprovement

brovement

DMAccess 2.0.2

- Improved Smart Offline Management
- Reader management improvement
- Contamination management improvement
- New webServices

## **C&C** Dosimetry Integration





## Dosimetry C&C Integration





#### **Value Proposition:**

- Proof that individuals have been properly monitored for contamination
- Save time at exit of RCA (read-out & switch-off dosimeter in parallel to contamination monitoring)
- Save space (combination of dosimetry and contamination monitoring stations)
- Identify potential sources/areas for contamination (through analysis of job-code vs. contamination events)
  - → Understand & reduce contamination events
- For some cases: C&C products can become an RCA entrance



## Dosimetry **C&C** Integration

#### **Key Features:**

- Direct integration of LD for DMC3000 in Argos-5)
- User ID is stored with measurement result
- Management of sequer configuration possibiliti
- LDMAccess software for reader is running on Argos empeaded computer
- **Result of contamination monitoring** (contam/clean) available in DosiServ

## Come to visit us



Start and End Dates

#### **Benefits**

e management

<del>Ability to analyze d</del>ata

64.762

4,681

=> Accelerate decisions & actions

Time saving / cost saving

=> Productivity Gains



Total People

113

113

## Updates





### Product End of Life

RAD60/62 & Ecosystem LBO (End of 2024)

Breakout Session Dedicated

Thursday - Telemetry 11:30 - 12:30

Dallas A

- Customer Notification
- Last Buy Offer (End of 2025)




## Information update

#### Webinar

- Orion (9<sup>th</sup> October)
- DosiServ (22<sup>nd</sup> October)
- Support Orion RTLS
  - Customer references acquisition still ongoing
- Passive Dosimetry
  - Discussion ongoing for DSD cross sell (Instadose / OSL / DIS)
  - DosiServ interface with DIS-1 / Instadose / BeOSL
  - DosiServ Cross sell distribution with DSD (ongoing)



## Dosimetry & Telemetry: Vision 2030



Communication

MIRION 24

Annual Users' Conference

Engage. Explore. Empower.



# Thank you We look forward to seeing you at the HP booth



